



Instruction using Aquapour 4015

1. Remove the desiccant bag and mix the material in the drum very well before adding water.



2. To avoid airholes on the surface you can put the material under vacuum before pouring into the tool.



3. Demolding is depending on the tool. If you have complex geometries you have to use multifid tools with a smooth surface finish.

